



Setting Up the Monitor

Before you set up the monitor, read through "Safety Precautions." To add the monitor to your workstation:

1. Turn off your monitor and workstation.
2. Disconnect and remove the monitor currently in place. Place the new monitor in your work area.
3. Connect the monitor power cord to the ~ connector on the back of the monitor.
4. Connect the monitor video cable to the □ connector on the back of the workstation.
5. Plug the monitor power cord into an appropriate outlet.
6. Turn on the monitor.
7. Turn on the workstation.
8. After the monitor has been on for at least 20 minutes, turn off the monitor power. Wait a few seconds, and turn on the power again. This degausses the monitor for correct display.

Adjusting Display Quality

To adjust the quality of the monitor display to your preferences, use the hand-held remote-control device.

1. Press on the ⚙▲ and ●▲ buttons on the remote control device until the screen is at maximum brightness.
The LED indicator light blinks quickly as the monitor receives remote commands. When at the maximum (or minimum) adjustment, the LED blinks slowly if you continue to press the button.
2. Display a file or screen with some vertical and horizontal lines (windows or graphics, for example).
3. Look at a dark area (such as a character or bar in a graphic) on the screen, press down on

▼⚙ until the dark areas on the screen begin to turn from gray to black.

4. Look at a white area on the screen, and press down on ▼● until the screen is at a comfortable viewing level.
5. While looking at any vertical line on the screen, press and hold down ◀(●●) or (●●)▶. The vertical red and blue lines should converge with the vertical green line. The vertical lines separate into red, green, and blue if this adjustment is not correct.
6. While looking at any horizontal line on the screen, press and hold down ▼(●●) or (●●)▲. The horizontal red and blue lines should converge with the horizontal green line. The horizontal lines separate into red, green, and blue if this adjustment is not correct.

If the image position on the screen needs adjustment, use the ◻ or ◻ controls described in "Controls, Indicators, and Connectors."

Cleaning the Screen

To remove dust from the screen, wipe it with a soft, dry, clean cloth. To remove more difficult dirt, such as fingerprints:

1. Wipe the screen with a soft cloth and a solution of isopropyl alcohol and water mixed with a mild detergent, or an ammonia-based window cleaner.
2. Rinse the screen immediately with a cloth dampened with clean water.
3. Dry the screen with a soft, clean cloth.



Caution – Never use abrasive materials to clean the screen. Scouring pads, abrasive cleaners, acid solutions, and chlorinated cleaners can damage the antireflective coating and should not be used.